STREAM MAINTENANCE Guide to removal of debris from KY waterways

Log jams, fallen trees, sediment (silt/sand and/or gravel), debris and other materials can build up and obstruct flow in ditches, streams, culverts, and under bridges during and after periods of heavy rainfall.

Though these types of obstructions are natural and part of a healthy creek system, some obstructions may create an increased risk of flooding, property and infrastructure damage, and result in erosion or increased sedimentation. In these cases we can remove the blockage using Best Management Practice guidelines that restore flow, but do not damage the creek, or make flooding issues worse.

This guide is designed to inform property owners of what they can do in the creek to remove obstructions safely and efficiently, and what activities require a permit.

Why Care About Healthy Streams?

A healthy stream ecosystem is the best defense against flooding and erosion problems on your property. When we straighten, armor, and remove vegetation from streams, we increase the amount of water entering the creek and the speed at which it travels, commonly resulting in damaging high waters and accelerating land loss due to erosion.

By protecting the plant communities near streams through wise stream management practices, we can ensure good water quality, reduce flooding likelyhood, and keep our property from washing away.

Plant roots in the riparian buffer help anchor the sediment and prevent erosion

mmunities

S


() () ()

5

Plants also help filter pollution from runoff, keeping it out of the creeks

Rough stream bottoms and meanders help dissipate energy and slow down flood waters Fallen trees are important habitat and food for aquatic ecosystems $\overline{\sigma}$

S



What happens upstream affects those living downstream! Good Stewardship Practices in the creek are one way we help protect not only our own land, but our neighbors as well.

Avoid working in the stream during fish spawning season (April 15- June 15).

You Need a Permit When...

You can't work from the bank and have to enter the stream with equipment.

Planning to work in a protected stream, such as Outstanding State **Resource Waters.**

Excavating gravel for commercial sale.

Installing bank stabilization structures.

Building culverts, bridges and low water crossings in the stream.

Still not sure if you need a permit? Contact KDOW to find out!

For More Information Contact

Kentucky Division of Water 300 Sower Blvd. Frankfort, KY 40601 Email: water@ky.gov Phone: 502-564-3410 Website: water.ky.gov/waterquality



MORE TIPS Try to limit gravel removal to one excavation per year.

from the bank.

Gravel excavation should be conducted only during low-flow, preferably in late summer or fall.